



PRODUCT DESCRIPTION



DISPOSAL / RECYCLING









IMPORTANT SAFEGUARDS

To ensure that your lamp lasts, please see below recommendations.

- 1. Make sure that the rating label of the adapter corresponds to the power output of the usage environment.
- 2. Only use indoors.
- 3. See **CLEANING & MAINTENANCE** for the correct procedures.
- 4. Do not exceed 2 500 rotations of the lamp head. One rotation: from a lower position to an upper position, then back to a lower position, or, vice-versa.

CLEANING & MAINTENANCE

- 1. Always unplug the lamp from the power supply before cleaning.
- 2. Wipe all surfaces with a damp cloth. DO NOT use detergents and/or abrasives. DO NOT immerse lamp in water (IP20).

WARRANTY

- Warranty ensures that this product will operate for the period of 1 year based on an average usage of up to 8 hours per day when used in accordance with the specification and directions stated in this manual.
- If this product fails to conform to the warranty a replacement product is guaranteed upon presentation of a valid sales receipt

PRODUCT SPECIFICATION

PART NUMBER	810-L20B (Black) : 810-L20W (White)
Color Temp (Kelvin)	4000 ± 200 K
CRI	RA ≥ 93
Brightness (40 cm distance)	1100 / 880 / 660 / 440 / 220 Lux ±10%
Lumen	400 lm ±10
Eco-timer	4 Hours
USB Charger (Type-A)	DC 5V2.1A
Life time	25 000 Hours
AC / DC adapter:	AC 220~240V, DC 12V 2A, Max 24W
Power Consumption	7W Max. 24W
Weight	750 g ±1%
Operating Temperature	-10 — 40 °C

INSTALLING FOR USE

- Unpack and place the desk lamp on a flat surface.
- 2. Change the angle of the lamp head by rotating the head anywhere from 10° to 130° depending on the intended use.
- 3. Connect the adapter to the back of the lamp and plug the adapter into an electrical socket.
- 4. Turn on by lightly touching the ON/OFF symbol. Eco-timer: The lamp automatically turns off after 4 hours of usage.